


Thank you for choosing our screen.


Read this manual carefully to ensure proper usage, you may also find the solution if you have problems.

IMPORTANT ATTENTION the installation of the screen, the electric connections, the setting of the limit switches, must be made from trained engineer only.

THE SHAPE OF SCREEN




MOTORIZED SCREEN WITH SWITCH BOX



MOTORIZED SCREEN WITH REMOTE CONTROL

INSTALLATION INSTRUCTION

- Unpack the screen carefully, be sure the screen is in good condition, check all the accessories are packed inside the carton.
- Check the voltage and frequency marked on the screen is in accordance with the local power supply. It is suggested only to use the screens indoor under normal temperature and humidity.
- Refer the fig below to fix the screen to the wall or to the ceiling.



FIX THE SCREEN TO THE WALL

FIX THE SCREEN TO THE CEILING

VOLTAGE AND FREQUENCY

Choose the voltage according to the local requirement: 110V/60Hz or 220V/50Hz.

INSTALLATION NOTE

- Must be installed from direct sunlight.
- Proper ventilation place.
- proper dampness.
- Clear place.
- Avoid violent jarring.
- Avoid the direct air current from air-condition, heater etc. Do not expose the screen in the High or Low temperature condition.